



# Omni-ID Sato CL4NX Guide

Omni-ID office locations: US | UK | China | India | Germany

Please refer to [Sato](#) and [NiceLabel](#) user guides for detailed instructions

---

CONTENTS

|  |    |
|--|----|
| PRINTER SETUP .....                                  | 3  |
| RIBBONS .....  | 5  |
| PRINTER SETTINGS .....                               | 6  |
| OPTIMIZED ENCODING SETTINGS FOR OMNI-ID LABELS ..... | 9  |
| SOFTWARE SETUP .....                                 | 11 |
| PRINT TROUBLESHOOTING .....                          | 14 |
| ENCODING TROUBLESHOOTING .....                       | 14 |
| LABEL ORIENTATION .....                              | 15 |
| ENCODING STANDARDS .....                             | 17 |


PRINTER SETUP

The following photographs will help you to load label rolls in the printer correctly.

1. Load label spool and lock in place with the **Guide Arm**.



2. Slide **Guide 2** to the rightmost position and then move it back left to secure the label.



**Guide 2**  
move to right most position



**Guide 2**  
move back to secure media


Note: The Sato CL4NX has a sliding Gap and I-Mark sensor arm.

3. Locate the **Gap Sensor** to a position where it is able to detect the start and end of the RFID label.



**I-Mark sensor**      **Gap sensor**

4. Feed the labels under the **Print Head**





**Pressure dial (start low and increase)**

Head pressure dials are located on top of the print head; these should be adjusted so that the print quality is consistent without applying excessive pressure.

5. **Final result**

The routing path of the media is as shown on the right figure.  
When loading the media, make sure that the print side faces up.

- Face-in media
- - - - Face-out media



## RIBBONS


Omni-ID has validated ribbon compatibility with:

| Manufacturer | Product      | Type                     |
|--------------|--------------|--------------------------|
| SATO         | Y70110200720 | Full resin carbon ribbon |




Load the ribbon into the printer so that the matt surface is visible to the human eye from the front of the printer.

The matt surface is the printing side and correct positioning will ensure correct printing onto the media.



The routing path of the ribbon is as shown on the right figure.

- Face-in ribbon
- - - - Face-out ribbon



## PRINTER SETTINGS

This section provides specific details and guidelines associated with encoding Omni-ID labels.

1. Setup RFID functionality of the printer, using the main control panel.



### Printer must be calibrated for each label correctly

Gap sensing: Gap sensing must be used at all times; this will use the leading edge of the frame label to align the print with the commands sent from your software. Calibration of the Gap levels is required each time a different label type is used. This can be found under advanced printer settings, Gap Levels.



### Important Settings

**Darkness:** Darkness should be adjusted to achieve optimal print quality.

**Slowest speed:** The slowest print speed that is available should be used to print

**Compound labels:** This is typically 2 inches per second.

**Advanced printer adjustments:** Pitch and offset should be set to 0mm.

**Print Mode:** Print Mode should be set to continues, with No Back feed. This is to avoid causing damage to the printer. The thicker IQ labels can damage the RFID antenna bracket if the off mode is used. This is due to the labels catching on the bracket as they back feed.

### Printer Antenna

Sato CL4NX offers two antennas for RFID encoding: Standard and Short. Only one antenna can be used for encoding, not both at the same time. For encoding Omni-ID labels the **Short** antenna is recommended.




## Prioritize

The printer settings can be prioritized to override the command settings and we do recommend you do this to avoid any erroneous settings in the command reaching the printer.

Command settings are those created in the label design software and the default setting on the printer.

On the printer menu screen:

- Printing
- Advanced
- Prioritize
- Settings
- ✓ when complete




## OPTIMIZED ENCODING SETTINGS FOR OMNI-ID LABELS

To achieve the best performance when encoding, the power should be set to the certified level. This level has been validated to ensure that adjacent labels are not programmed in error (\*).

(\*) due to the size of the small IQ Label tags the sensor in the print head can sometimes detect the information from the tag behind, so it is necessary to change the sensor pitch to read the right tag and print the associated information.

### 5.3.2 Adjusting the Print Position

Set the Pitch in the **Printing > Advanced > Adjustments** menu to adjust the print position.




#### Note

The above base reference point (print position) will be the stop position when the sensor type is set to Gap sensor.

The maximum pitch offset on the Sato CL4NX printer menu system is -3.75mm so if the pitch offset is more than that, you must set it in the NiceLabel software:

- Print Mode
- Backfeed
- Pitch offset




The table below provides the optimal settings for all variants of Omni-ID IQ Label tags:


| Omni-ID Tag              | Menu/Settings  |          |       |             |            |               |               | Menu/Interface/RFID |             |            |            | Menu /Printing /Advanced |
|--------------------------|----------------|----------|-------|-------------|------------|---------------|---------------|---------------------|-------------|------------|------------|--------------------------|
|                          | Darkness Range | Darkness | Speed | Sensor type | Print mode | Advanced      |               | Antenna pitch       | Write power | Read power | Tag offset | Pitch                    |
|                          |                |          |       |             |            | Calibrate Gap | Adj. / Offset |                     |             |            |            |                          |
| IQ 400P                  | F              | 10       | 2     | GAP         | CONT       | AUTO          | 0             | SHORT               | 18          | 14         | 0          | 0                        |
| IQ 800P                  | F              | 10       | 2     | GAP         | CONT       | AUTO          | 0             | SHORT               | 17          | 11         | 0          | 0                        |
| IQ 1200G - EU            | F              | 10       | 2     | GAP         | CONT       | AUTO          | 0             | SHORT               | 18          | 16         | 0          | 0                        |
| IQ 1200G - US            | F              | 10       | 2     | GAP         | CONT       | AUTO          | 0             | SHORT               | 19          | 18         | 0          | 0                        |
| IQ 800G                  | F              | 10       | 2     | GAP         | CONT       | AUTO          | 0             | SHORT               | 14          | 14         | 0          | 0                        |
| IQ 150 - US - with GP    | F              | 10       | 2     | GAP         | CONT       | AUTO          | 0             | SHORT               | 16          | 12         | 0          | -4                       |
| IQ 150 - EU - with GP    | F              | 10       | 2     | GAP         | CONT       | AUTO          | 0             | SHORT               | 24          | 20         | 0          | -4                       |
| IQ 150 - US - without GP | F              | 10       | 2     | GAP         | CONT       | AUTO          | 0             | SHORT               | 22          | 15         | 1          | 0                        |
| IQ 150 - EU - without GP | F              | 10       | 2     | GAP         | CONT       | AUTO          | 0             | SHORT               | 22          | 20         | 0          | 0                        |
| IQ 350 - US with GP      | F              | 10       | 2     | GAP         | CONT       | AUTO          | 0             | SHORT               | 14          | 12         | 1          | 0                        |
| IQ 350 - EU with GP      | F              | 10       | 2     | GAP         | CONT       | AUTO          | 0             | SHORT               | 14          | 12         | 1          | 0                        |
| IQ 600 - US - with GP    | F              | 10       | 2     | GAP         | CONT       | AUTO          | 0             | SHORT               | 22          | 15         | 10         | 0                        |
| IQ 600 - EU - with GP    | F              | 10       | 2     | GAP         | CONT       | AUTO          | 0             | SHORT               | 22          | 15         | 10         | 0                        |
| IQ 600 - US - without GP | F              | 10       | 2     | GAP         | CONT       | AUTO          | 0             | SHORT               | 22          | 15         | 10         | 0                        |
| IQ 600 - EU - without GP | F              | 10       | 2     | GAP         | CONT       | AUTO          | 0             | SHORT               | 22          | 15         | 10         | 0                        |


## SOFTWARE SETUP

Recommended software for Sato CL4NX is NiceLabel Pro, Please Refer to NiceLabel Designer Pro user guide for detailed instructions (link is on Page 2)




Insert label dimensions






Check all boxes in "Print Setting"


Use print settings from the printer.



To enable RFID encoding, choose the RFID settings



The "Feed without print" box is checked by default. Please uncheck this box. If box is checked, printer will not print and only encode the labels.



## PRINT TROUBLESHOOTING

| Issue                     | Possible Cause                        | Solution   |
|---------------------------|---------------------------------------|--|
| Labels won't feed         | Sensor location<br>Sensor setting     | Re-locate sensor<br>Check gap sensing in menu<br>Re-calibrate sensor if necessary. |
| Barcode not straight      | Labels slipping                       | Increase head pressure or change roller under head                                 |
| No print at all           | Ribbon in upside down<br>Wrong ribbon | Turn ribbon around<br>Change ribbon to known good ribbon.                          |
| Partial print on one side | Head pressure                         | Re-balance   |
| Print blurring            | Too much ink                          | Reduce darkness  |
| Print too light           | Too little ink                        | Increase darkness<br>Slow print speed<br>Increase head pressure both sides         |

## ENCODING TROUBLESHOOTING

| Issue   | Possible Cause                            | Solution                                    |
|---|---|---|
| Multi tag error   | Reading more than one tag                 | Turn the read power down                    |
| Tag not found   | Cannot read or write the tag              | Adjust the read and/or write power          |
| Read only error   | Calibration is wrong                      | Turn the write power up                     |
| Encoding adjacent label   | The distance between labels is too small  | Adjust Tag offset                           |
| Printer missing tag between each printed tag                                | Gap Levels Incorrect                      | Re calibrate Gap Levels                     |
| Print without RFID encoding   | 'Write data to RFID tag' deselected       | Select 'write data to RFID tag' in s/w      |
| WRITE TAG ERROR displayed on label and RFID tag error code # 1018 displayed | Encoding data type is set to ASCII string | Select HEX encoded string in data type menu |


## LABEL ORIENTATION

Omni-ID IQ Label tags are supplied on the roll with the media facing out and the antenna facing up. This is the position the labels should be retained in for successful encoding and printing.

If in any instance you unroll the labels (i.e. to split a large roll into a smaller roll), you must ensure to re-roll them in the correct orientation.

The images below show the antenna exposed and in the correct orientation:


### **IQ 150 in printer – media facing out, antenna facing up**



### **IQ 600 in printer – media facing out, antenna facing up**



IQ 350 in printer – media facing out



## ENCODING STANDARDS

Omni-ID tags can be encoded with any hexadecimal code, however GS1 have interoperability standards which can be used to help in situations where multiple organizations need to read the tag.

Examples of such standards include: SGTIN-96, GIAI-96 and GID-96

It is the Users responsibility to define the code if Omni-ID is providing service bureau.

See "[Omni-ID Standard Service Bureau reference guide](#)" for assistance with sequencing compliance

### Example of GID-96bit scheme:

|  | Header | General Manager Number | Object Class | Serial Number |
|--|--------|------------------------|--------------|---------------|
| <b>Data</b>                                    | 8bits  | 28bit                  | 24bit        | 36bit         |
| <b>Number of Hexadecimal characters</b>        | 2      | 7                      | 6            | 9             |
| <b>Example of data string (in Hexadecimal)</b> | 35     | 23AFB84                | AB12FE       | 00000001      |

**Header** – This is a static binary number (which is converted into hexadecimal) that identifies that the coding system being used is GID-96bit.

**General Manager Number** – This is a number which identifies the Company which is responsible for allocating the object class and the serial number, this is assigned by GS1/EPC global.

**Object Class** – This number defines the type of item that is being tagged, this might be a type of hardware, or a component in a larger assembly.

**Serial Number** – This is the unique number used to identify the specific item, typically this is the part of the EPC number that this serialized.